



## **Part No 90700**

### **Jeep TJ 6" front fender Flare support Kit (pair)**

### **For: 97-06 Jeep TJ Front Flat Panel Flares #9071 & #9072**

#### **PLEASE READ INSTRUCTIONS THOROUGHLY BEFORE PROCEEDING**

We have provided complete instructions and specific hardware, The list of these items is listed on the page 2 of the instructions.

--Before starting please verify that they are included with the shipment. Also, verify that you received the correct part(s).

Tools and general materials required: Sockets, socket wrench and hand wrenches

#### **THERE ARE TWO PHASES TO THIS INSTALLATION:**

- 1) Removal of some mounting hardware
- 2) Installation of the #90700 support panels (left and right)

#### **PHASE 1) REMOVAL OF FRONT RIGHT AND LEFT FLARES**

- REMOVE the oval side marker light from the flare and save (do not disconnect the wires)
- REMOVE the mounting hardware from holes #3, #4, #5 and #6 (the first front mounting hole is considered #1)

**IMPORTANT:** At this point it is important that the Jeep be in the sun on a warm day or in a well heated area. This heat will allow the flare to seek it's as molded shape after the support panel is installed.

#### **PHASE 2) INSTALLATION OF THE SUPPORT AND FENDER FLARE**

**-WITHOUT letting the flare cool place the support panel under the flare remembering that the first hole in the support panel aligns with the mounting hole #3 in the body, Secure the support**

**Page Two**

**panel with the provided four 1/4 x 20 x 1" bolts, washers and nylock nuts and tighten these 4 fastners after aligning the top of the flare so it is flat.**

**-REINSTALL the side marker light assembly.**

**PART NUMBER(S): 90700 Right and left support panels (90701 and 90702)**

**HARDWARE PROVIDED: (1 EA)-Left and Right Support Plates, (8)- 1/4" x 20 x 1" stainless steel bolts, (8)- stainless steel washers, (8)-1/4" x 20 nuts, (1) set instructions**